



## Our Pro Tips

Below are some generic guidelines for our wood products. Please let me know if you have any questions.

- I recommend thoroughly testing & documenting the sub flooring before delivery of the product.
- "Sticker" out each board, so they can evenly acclimate (we use lath).
- Use a flexible adhesive ([Wakol MS 262](#) is very good), NOT ONE THAT IS RIDGID OR DOES NOT ALLOW MOVEMENT!
- Test & verify/document MC levels of product a day after delivery. (Product needs to adjust to temp for proper readings).
- There is a moisture barrier roll-on we recommend (if there is a source of moisture) - [Wakol PU 280](#) - Use 1 coat on plywood or 2 coats over concrete.
- For 4" widths and less, use [Aquibar](#) underlayment paper.
- Full-time mechanicals MUST be up & running 3 weeks before delivery of product - This is seasonal - Cooling season: AC & dehumidifiers, Heating season: heat & humidification.

Thank you for doing business with Hunt Hardwood.

Regards,

A handwritten signature in cursive script that reads "Patrick T. Hunt".

Patrick T. Hunt  
Cell: 781-953-1514